

HLK-B20 User Manual

BLE 4.2 wireless module



1. Product description	1
1.1. Basic parameters	1
2. Product Overview	2
2.1. Technical specifications	2
Table 2-1 Product Specifications	2
2.2. Hardware description	2
2.3. Block diagram	3
2.4. Default pin function	3
3. Test board description	4
3.1. Restore factory settings	4
4. Function description	5
5. Serial port working state conversion	5
6. Led light indication meaning	6
7. Parameter configuration method	6
8. Serial port AT command configuration	6
8.1. AT instruction format	6
8.1.1. Ver	7
8.1.2. Uart	7
8.1.3. net_commit	7
8.1.4. Reconn	7
8.1.5. ble_status	8
8.1.6. ble_name	8
8.1.7. default	8
8.1.8. Reboot	8
9. Configuration Tool Description	9
10. Transparent transmission minimum system	9
11. Bluetooth data transmission	10
12. Reflow soldering temperature curve	12
Appendix A Document Revision History	. 13

Contents



1. Product description

HLK-B20 is an new low-consumption Bluetooth BLE 4.2 control module made by Hi-Link. This product is a Bluetooth-compliant module based on universal serial interface. It has built-in BLE 4.2 protocol stack, which can realize data conversion between user serial port and Bluetooth interface.

1.1. Basic parameters

- High-speed ARM9E core MCU
- 2.4G/1T1R, BLE 4.2
- 160k programming space, 20KB RAM
- Power supply voltage 0.9-3.6v
- Ultra low supply voltage, low power consumption
- Built-in crystal, high stability
- Small chip package 4x4
- Rich peripheral interface, SPI, I2C, ADC, UART, PWM, GPIO
- Widely used in the Internet of Things
- High-speed 10-bit multi-channel ADC with internal filtering
- Easy to connect, fast speed



Manual

2. Product Overview

2.1. Technical specifications

1 uole 2 1 1 loudet opeenteutions

Transfer Protocol	Bluetooth standard : BLE 4.2
Supply voltage	0.9-3.6V
Air speed	1 Mbps
Number of channels	2.4g:1-14
Frequency Range	2400-2480MHZ
Transmit power	4DB
Receiving sensitivity	-96dbm
Received power	5.1ma
Transmit power	4.5ma
Antenna type	External /internal antenna
Other parameters	
Status indicator	Status indication
	Operating temperature: -40-125°C
Environmental standard	Working humidity: 10%-90%RH (Non-condensing)
	Storage temp.: -40-90°C
	Storage humidity: 5%-90%RH (Non-condensing)
Other performance	Band bandwidth optional: 1MHz

2.2. Hardware description

HLK-B20 dimension as below:(L*W)=16mm*25mm



Figure 1 HLK-B20 Dimension

Manual

2.3. Block diagram



Figure 2 HLK-B20 Module architecture diagram

Default phi function				
No.	Network name	Туре	Function description	Default features
1	RSTN	Ι	Chip enable, high efficiency	CPU reset
2	P07	I/O	P07,SPI_NSS,PWM5	GPIO,SPI,PWM
3	P14	I/O	P14,PWM4	GPIO,PWM
4	P10	I/O	P10,PWM0	GPIO,PWM
5	P11	I/O	P11,PWM1	GPIO,PWM
6	P12	I/O	P12,PWM2	GPIO,PWM
7	P13	I/O	P13,PWM3	GPIO,PWM
8	3V3	Р	3.3V power supply	Power
9	P31	I/O	P31	GPIO
10	P32	I/O	P32	GPIO
11	P17	I/O	P17,uart2_rxd	GPIO,uart2
12	P16	I/O	P16, uart2_txd	GPIO,uart2
13	P34	I/O	P32	GPIO

2.4. Default pin function



HLK-B20

	Sh	enzhen l	Hi-Link Electronic Co., Ltd.	Manual
14	P33	I/O	P33	GPIO
15	GND	Р	GND	GND
16	P02	I/O	P02,SCL	GPIO,I2C
17	P03	I/O	P03,SDA	GPIO,I2C
18	P04	I/O	P04,SPI_CLK	GPIO,SPI
19	P05	I/O	P05,SPI_MOSI	GPIO,SPI
20	P06	I/O	P06,SPI_MISO	GPIO,SPI
21	P01	I/O	Uart1_rxd	Uart1, Transparent transmission serial port
22	P00	I/O	Uart1_txd	Uart1, Transparent transmission serial

3. Test board description

The test board is mainly used to test the data transmission function of the HLK-B20's Bluetooth and serial ports.



Figure 3 HLK-B20 module test board

3.1. Restore factory settings

To ensure that all configuration procedures are correct, first reset the module to factory settings. Modules that are already in factory mode can skip this step. Provide 5V (1000mA) power supply to power on the module, wait for about 1 second, let the module start up. After the startup is completed, pull down the ES0 (PIN5) pin for more than 6S. When the LED corresponding to the STA is always on, it means that the module is restored the factory settings successfully, then release the ES0 pin, the system will automatically restart. The system is already in factory mode after rebooting.

4. Function description

The module function is mainly to realize the mutual conversion of Bluetooth data and serial data.



Figure 4 Serial to BLE mode

In this mode, the BLE Bluetooth device transmits the data to the HLK-B20 module via Bluetooth, and the HLK-B20 module sends the received data from the serial port. When the serial port gets data, the HLK-B20 sends the serial port data from the Bluetooth terminal to realize the conversion of serial data and Bluetooth data. When the HLK-B20 has a Bluetooth device connected, the HLK-B20 will turn off the broadcast of the Bluetooth name, and other Bluetooth devices will no longer be able to connect to the HLK-B20.

5. Serial port working state conversion

The module defines the working state of the serial port as two modes: transparent transmission mode and AT command mode.



Figure 5 . Serial port working state transition

After normal power-on, the module directly enters the transparent mode. If Bluetooth is not connected, the data will not be sent out from Bluetooth. If Bluetooth is connected, the data will be sent out from Bluetooth. In any state, keeping the ES0 pin low for longer than Tes and less than Trst will immediately enter the AT command mode.





Figure 6. RST Exit transparent mode

Notes: Tes=100ms, Trst=6s

6. Led light indication meaning

The status of the led connection module's P02 pin, corresponding to the sta led on the test board:

- * Double flash: Bluetooth is not connected, and is in transparent mode
- * Triple flash: AT command mode
- * Long extinction or fast flash: Bluetooth is connected, it will flash quickly when there is transparent data transmission

7. Parameter configuration method

The module configuration is mainly configured through the serial port AT command. To configure parameters through the serial AT command, you need to let the module enter the AT command mode first. The serial port configuration tool HLK-B20_CONFIG, that configures the module through the AT command mode, through the parameters of each configuration combinations, provides a simple and convenient configuration process.

Serial port AT command configuration AT instruction format

In AT mode, system parameters can be configured through the AT command of the serial port. The format of the instruction is as follows: at+[command]=[value]\r

Different return values of the module will be returned depending on the different command.

Example: "at+ble_name=blename\r" sets the module broadcast address to blename. Example: "at+ver=?\r" queries the module program version number.



Manual

Command list as below:

ver	Module Version
uart	Serial port configuration
default	Restore factory setting
ble_name	Bluetooth name
net_commit	Submit configuration parameters
reconn	Restart the serial port service
ble_status	Bluetooth connection status
Reboot	Restart the system

8.1.1. Ver

Function	Firmware version query
Format	at+ver=? \r
Parameter	No

8.1.2. Uart

Function	Serial port configuration settings
Format	at+uart= <baud>, <data>, <parity>, <stop>\r</stop></parity></data></baud>
Parameter	Baud: Baud rate
	Data: Data bit
	Parity: Check Digit
	Stop: Stop bit length

8.1.3. net_commit

Function	Submit network settings
Format	at+net_commit=< Net_commit >\r
Parameter	0: invalid
	1: Submit

8.1.4. Reconn

Function	Restart the serial port conversion service
Format	at+ reconn =< reconn >\r
Parameter	0: invalid 1: Restart the serial port conversion service



8.1.5. ble_status

Function	Query Bluetooth connection status
Format	at+ ble_status =?\r
Parameter	0: Not connected
	1: Connected

8.1.6. ble_name

Function	Query Bluetooth connection status
Format	at+ ble_name = <blename>\r</blename>
Parameter	blename: Bluetooth name

8.1.7. default

Function	Restore factory setting
Format	$at+default=1\r$
Parameter	No

8.1.8. Reboot

Function	Restart the system
Format	at+ reboot =1\r
Parameter	No



Manual

9. Configuration Tool Description

待发送命令	2 COM11 → 搜索模块
it-ble_name= it-uart=115200,8,n,1 it-inct_commit=1 it-reconn=1 1	篮牙无线参数 3 篮牙名称
	田口参数 4 波特率 115200 ▼ 数据位 8 ▼
ft分执行与回复 5	提交配置 6 査询配置 7 透传模式 8 恢复出厂 9
用户参数保存区 User0 S User1 S User2 S User3 S	



- 1: Command window to be sent
- 2: Serial port number selection
- 3: Bluetooth name setting
- 4: Serial port parameters
- 5: Serial port return command
- 6: Submit configuration
- 7: Query configuration
- 8: Enter transparent mode
- 9: Restore factory settings

10. Transparent transmission minimum system





11. Bluetooth data transmission

Bluetooth data transmission is that after the Bluetooth connection is successful, the module will send the data received from the Bluetooth by the serial port, and the data received from the module serial port will be sent out by the Bluetooth.

The module Bluetooth function only supports Bluetooth 4.2.

Install the Bluetooth mobile phone test software HLK-BLE.apk, open the Bluetooth function of the mobile phone, and then open the app, it will search for the Bluetooth name at the beginning of HLK-BLE_ on the app.

1.8. 10. 10.		● ☆ □	B 10:0
	设备	i列表	
HLK-H AE:4D prePar 02010	BLE_4DAE :18:3C:D6:40 se: 60303AA180D0948	R: 4C4B2D424C455F34	ssi: -47 44414
@Len = @Len = @Len =	arse: = 02, @Type = 0x01 = 03, @Type = 0x03 = 00, @Type = 0x09	-> 06 -> AA 18 -> HLK-BLE_4DAE	
NULL		R	ssi: -77
prePar postPa @Len #6	se: 02011A0AFF4C irse: = 02, @Type = 0x01 = 0A, @Type = 0xFF	0010050118376EF6 -> 1A -> 4C 00 10 05 01 18	37 6E
NULL	44 FB 43 1F	R	ssi: -79
prePar 1EFF00 186260 postPa @Len 1 86 B3 1	se: 5000109200277DA 60CA4463488DD7C0 irse: = 1E, @Type = 0xFF 85 D8 8F E4 00 E2 3	86B3B5D88FE400E23 CD -> 06 00 01 09 20 02 RA 95 E1 86 26 6C A4	3A95E 77 DA 46 34
	0 0		

Figure 9 Bluetooth search list



Figure 10 Bluetooth attribute list



Then input the sent data in the send box, click Send, the data will be received on the serial port, and the data sent by the serial port will be received on the app.

i SSCOM V5.13.1 串口/网络数据调试器,作者:大虾丁丁,2618058@qd	₩ 仅限紧急呼叫 🖋 🔇 🖸	* 🕼 🛜 🖪 💷 17:19
通讯端口 串口设置 显示 发送 多字符串 小工具 帮助 ▲	^{PC} 123456789	
123430105	发送数据	清空LOG
	Time(ms): 100	自动发送
	发送总长度:9 成功:9	失败: 0
	通知(NOTIFY): 🛛 🥌 接	秋 总长度:14
清除窗口 打开文件	[17:19:02:449] Send success Length: 9 [17:19:04:613] Receive by No , Length: 14	, Write: 123456789,
端口号 COM4 USB Serial Port	<u>接</u> <u>述</u>	
请您注册嘉立创时结尾客户 ▲ 基 【升级到SSCOM5 13.1】★PCB打样降至每款30元顺丰包邮!SMT贴片工程	费	
www.daxia.com S:14 R:9 COM4 已打开 11520		

Figure 11 Bluetooth transmission test



12. Reflow soldering temperature curve

When the module is over-fired, please strictly follow this temperature curve. If the temperature deviation of the reflow

soldering is too large, the module will be damaged!

Temperature setting (degrees Celsius)									
Warm zone	1	2	3	4	5	6	7	8	
Upper temperature zone	125	135	155	185	195	225	240	230	
Lower temperature zone	125	135	155	185	195	225	240	230	
Conveyor speed: 70.0 cm/min									



Seconds/S

PWI= 94%	Constant terr	perature time 175	~190°C	Reflux time	/220°C	Max temp.
<tc2></tc2>	35.53	-82%	55.58	-72%	230.28	-94%
<tc3></tc3>	37.66	-74%	58.66	-57%	230.56	-89%
<tc4></tc4>	41.52	-62%	60.63	-47%	233.62	-28%
<tc5></tc5>	37.07	-76%	60.44	-48%	231.67	-67%
Temp. difference	5,99		5.05		3.34	1941 - COM

Process boundary

Solder paste:	System Default for Reflow				
Statistic name		Minimum limit	Maximum limit	Unit	
Constant temperature	e time 175~190 °C	30	90	s	
Reflow time -220°C		50	90	S	
Maximum temp.		230	240	°C	



Appendix A Document Revision History

Version number	Revision Scope	Date
1.00		2019-4-15