


RM04 module GET WEB

In the following paper, we treat' get URL www.google.com.hk/imghp?hl=zh-CN&tab=wi' as an example to introduce the configuration methods of getting website content.

1, Module configuration



Note:

WiFi Parameter: SSID: router SSID Key: router password

Remote IP: The root URL you want to get, www.google.com.hk

Port: 80

2. Serial data sending

Txt format will be made of the following documents, send files using serial assistant:

GET / imghp?hl=zh-CN&tab=wi HTTP/1.1

Host: www.google.com.hk

Connection: keep-alive

Note: Blue part is the URL for the latter part of the get, If you want to get to the root domain URL, this part can be omitted, For example: get the web :www.google.com.hk,The content in the Txt is as follows:

GET / HTTP/1.1

Host: www.google.com.hk

Connection: keep-alive

3.The serial port will receive the get web content.